



Distance needed from wall for full recline: **6.5"**

*Rotate Sofa 90° to fit through the door before attaching backrest